

MANHOLE STEPS OF POLYPROPYLENE



MANHOLE STEPS OF POLYPROPYLENE



| FLAT FACE | | | | | CURVE FACE | | | | |
|-----------|-----|-----|-----|-----|-----------------|----|-----|-----|----|
| Model | A | B | C | D | Model | A | B | C | D |
| Bilbao | 80 | 160 | 330 | 85 | 12“(300) | 80 | 160 | 300 | 85 |
| Standar | 80 | 140 | 330 | 85 | 13”(330) | 80 | 160 | 330 | 85 |
| Barcelona | 100 | 120 | 330 | 105 | Measures in mm. | | | | |

The manhole step has a corrugated steel core of 12 mm. and is covered with COPOLIMERE POLYPROPYLENE of high impact resistance.

Manhole steps have patterned surface to avoid falls.

EASY TO INSTALL

Once concrete is hardened two 25 mm diameter holes are drilled to install the step. There should be a distance of 330 / 300 mm between the centre points of the two holes and a 85 / 105 mm depth (it is depend upon the model).

The manhole step should be tapped on each end alternately until fully inserted to a depth of 80 / 100 mm.

It is essential to check that the holes are drilled accurately. Otherwise there will be necessary to fill in with mortar or filler.

